

Cleaning & Care

- To remove the toilet seat for cleaning, depress the quick-release buttons and lift the seat upward.
- Clean the surfaces using only a soft cloth or sponge with warm water and a mild soap or detergent.
- Dry the seat and hinges thoroughly after cleaning to prevent long-term moisture buildup.
- Do not use scouring pads, abrasive cleaners, steel wool, or hard scrub brushes on any part of the unit.
- Do not apply solvents, bleach, harsh chemicals, or corrosive liquids, as these will damage the finish and materials.
- Note that the use of clip-on deodorizers will affect flushing performance on rimless suites.

Warranty

Component	Residential	Commercial
Dune Wall Hung Toilet Pan	5 years replacement parts or product, 1 year labour	3 years replacement parts or product, 1 year labour
Dune Toilet Seat	1 year replacement parts or product	1 year replacement parts or product
Toilet Seat Hinge Caps	1 year replacement parts or product	1 year replacement parts or product
S-Trap Pipe	1 year replacement parts or product	1 year replacement parts or product